

# **HAKKO** MODEL **SOLDERING STATION** **FM-202**

High-output, temperature controlled  
soldering station

## **Instruction Manual**



Thank you for purchasing the FM-202 soldering station. This high-output, temperature controlled soldering station uses a composite tip, incorporating heater and sensor functions into one element. Several process control features, unique to the FM-202, make it applicable to a broad range of soldering applications.

Please read this manual before operating the FM-202. Keep this manual readily accessible for reference.




### **TABLE OF CONTENTS**

1. PACKING LIST .....	1
2. SPECIFICATIONS .....	1
3. WARNINGS, CAUTIONS, NOTES AND EXAMPLES .....	2
4. PART NAMES .....	3
5. INITIAL SETUP .....	3
6. OPERATION .....	5
7. TIP IDENTIFICATION NUMBER .....	9
8. PARAMETER SETTINGS .....	10
9. MAINTENANCE .....	12
10. ERROR MESSAGES .....	14
11. TROUBLE SHOOTING GUIDE .....	15
12. PARTS LIST .....	17
13. TIP STYLES .....	20
14. APPENDIX A .....	22
15. WIRING DIAGRAM .....	23

# 1. PACKING LIST

FM-202 soldering station .....	1	Heat resistant pad .....	1
FM-2021 connector assembly .....	1	Tip tray .....	1
Sleeve .....	1	Iron holder .....	1
Sleeve stopper .....	1	Cleaning sponge .....	1
Power cord .....	1	Instruction manual .....	1
Control card, with chain .....	1	Tips (not included)	



# 2. SPECIFICATIONS

## ● FM-202 soldering station

Power consumption	75 W (Max. 130 W)
Temperature range	200 – 450°C (400 – 840°F)
Temperature accuracy	±10°C (±18°F) of set temperature. See Figure 1.
Temperature stability	±5°C (±9°F) at idle temperature

## ● Station

Output	24 V
Dimensions (l x w x h)	178 x 119 x 117 mm (7.0 x 4.7 x 4.2 in)
Weight	2,700 g (5.9 lb.)

## ● Soldering iron

Power consumption	70 W (24 V)
Tip to ground resistance	< 2 Ω
Tip to ground potential	< 2 mV
Length, less cord	188 mm (7.4 in.) with 2.4D tip
Weight, less cord	30 g (0.067 lb./1.07 oz.) with 2.4D tip
Length of cord	1.2 m (4 ft)





Figure 1. Temperature accuracy and stability.


## NOTE:

This product is protected against electrostatic discharge. Specifications and design are subject to change without notice.

## 3. WARNINGS, CAUTIONS, NOTES AND EXAMPLES

Warnings, cautions and notes are placed at critical points in this manual to direct the operator's attention to significant items. They are defined as follows:

 **WARNING:** Failure to comply with a WARNING may result in serious injury or death.

 **CAUTION:** Failure to comply with a CAUTION may result in injury to the operator, or damage to the items involved. (Two examples are given below.)

**NOTE:** A NOTE indicates a procedure or point that is important to the process being described.

**EXAMPLE:** An EXAMPLE is given to demonstrate a particular procedure, point or process.

### CAUTION

When power is ON, tip temperatures will be between 200 and 450°C (400 to 840°F). To avoid injury or damage to personnel and items in the work area, observe the following:


- Do not insert any foreign substance or incompatible tip into the process gate.
- Do not insert the tip end of the cartridge into the process gate.
- Do not touch the tip or the metal parts near the tip.
- Do not allow the tip to come close to, or touch, flammable materials.
- Inform others in the area that the unit is hot and should not be touched.
- Turn the power off when not in use, or left unattended.
- Turn the power off when connecting the FM-2021 or storing the FM-202.
- Do not remove or damage the bar code sticker.

### CAUTION

To prevent accidents or damage to the FM-202, be sure to observe the following:

- Do not use the FM-202 for applications other than soldering.
- Do not allow the FM-202 to become wet, or use it with wet hands.
- Do not modify the FM-202.
- Use only genuine Hakko replacement parts.
- Do not bend or damage the control card. If the card does become damaged, do not force the card into the station slot.
- Do not strike the iron against hard objects to remove excess solder. This will damage the iron.
- Remove power and iron cords by holding the plug – not the wires.
- Be sure the work area is well ventilated. Soldering produces smoke.


## 4. PART NAMES



## 5. INITIAL SETUP

### A. Iron holder


1. Adjust the height of the iron holder to suit, as follows:
  - i. Loosen the adjusting screws.
  - ii. Set the iron holder to the desired height.
  - iii. Tighten the screws.



2. Put the small cleaning sponge in one of the four holes in the iron holder base.
3. Add water to the level shown in the accompanying illustration. The small sponge will keep the large sponge moist through capillary action.
4. Wet the large cleaning sponge, squeeze it dry, and put it on the iron holder base.  
 Procedure 2-4 -OR-  
 Wet the large cleaning sponge, squeeze it dry, and put it on the iron holder base.
5. Place the spare tips in the tip tray.


**NOTE:**

Be sure the cleaning sponge is kept CLEAN and DAMP. A dirty sponge will transfer contaminants to the soldering tip, reducing thermal efficiency and possibly causing defective solder joints. A dry sponge will abrade the soldering tip, reducing its life.



## B. Connector cord

Pass the connector cord through the hole in the heat resistant pad.




## C. Soldering station

**CAUTION:**

Be sure the power switch is OFF before connecting or disconnecting the soldering iron cord. Failure to do so may result in damage to the circuit board.

1. Insert the power cord into the receptacle at the back of the station.
2. Insert the connector cord into the receptacle at the front of the station.
3. Plug the power cord into a grounded wall socket. The FM-202 is protected against electrostatic discharge and must be grounded for full efficiency.

When the plug clicks , it is fully inserted.




Push the plug in as far as it will go, and try to remove it without pressing the release pin. If it stays in the receptacle it is properly seated.

# 6. OPERATION

## Controls and displays

### Controls



The front panel of the FM-202 soldering station has four control buttons, the process gate, the receptacle, and the card slot. The power switch is on the back panel.

- Four control buttons:

- **#** – Initiates the Tip ID entry mode. When pressed for less than one second, the stored Tip ID is displayed. When pressed for more than one second, the Tip ID entry mode is activated.
- **\*** – Initiates the temperature setting mode. When pressed for less than one second, the stored temperature is displayed. When pressed for more than one second, the temperature entry mode is activated.
- **▲** – Increases the value in the appropriate display window.
- **▼** – Decreases the value in the appropriate display window.

### Displays

The FM-202 has a three-digit display element. Depending upon the selected mode, it will display:

- Normal mode:  
Sensor temperature (tip temperature)
- Data entry:  
Selected quantity (see 'data entry procedures' for exact characteristics)
- Temperature scale:  
°C or °F, depending upon selection
- Error detection:  
Refer to 'ERROR MESSAGES' section



In addition, a single heater lamp will flash when the station has reached the desired temperature, indicating that it is ready for use.

An audible buzzer is provided to alert the operator:

- When the station has reached the set temperature. The buzzer will sound once.
- When the tip is inserted into the process gate, the buzzer will sound once when the Tip ID bar code has been read.
- When the low temperature threshold has been crossed, the buzzer will sound continuously. The buzzer will shut off once the sensed temperature returns to the acceptable range.
- When a foreign substance, an incompatible tip, or the soldering end of the tip is inserted into the FM-2021, the display will flash and the buzzer will sound continuously.
- When the auto power shutoff is activated and power to the heating element is turned off, the buzzer will sound three times.
- When the process gate cannot read the Tip ID bar code, the buzzer will sound three times.
- When a tip insert into the process gate while the tip is already in the FM-2021, buzzer will sound irregularity.
- When the tip is properly inserted into the connector, the buzzer will sound once.

**NOTE:**

This procedure must be followed EVERY TIME THE STATION IS TURNED ON.

1. If a tip is in the connector, remove it; remove the tip from the sleeve assembly as well.
2. Turn the power switch ON.
3. The display will show  and the LED on the connector will flash.
4. Enter Tip ID as follows:  
Insert the Tip ID end of the tip into the process gate until the buzzer sounds once. Tip ID data are displayed for one second. The display shows . The LED indicator will stop flashing. Indicating that they are now stored.  
(Refer to Appendix A for manual entry.)
5. Inserting the tip:  
Hold the head part of the tip and insert the tip into the sleeve assembly. Push until the sleeve assembly touches the ring round the tip; at this point the tip should not be forced further into the sleeve assembly.

There are no orientation requirements.






**NOTE:**


Once the tip is inserted into the connector, heat control begins.

6. When the set temperature is reached, the buzzer sounds and the heater lamp at the lower right of the temperature display starts blinking.


## Factory settings

The FM-202 comes from the factory with the following values preset:

Temperature scale		Fahrenheit
Auto power shutoff		disabled
Low temperature alarm setting		300 F
Resetting the supervisor or operator control setting		Tip ID controlled with inserting the card.
Set temperature		750 F



**NOTE:**

The FM-202 is preset at 750 F. at the factory. Check the temperature setting by pressing the  button. The set temperature will be displayed for two seconds.


**NOTE:**

If the buzzer sounds three times when the tip is inserted into the process gate, there has been a reading error. Reinsert the tip.

**CAUTION:**

Refrain from inserting foreign objects, the wrong end of the tip, or incompatible tips into the process gate. Damage may result.

**NOTE:**

When the power has been cycled, Tip ID is no longer stored in the station and  will flash. Reenter Tip ID as shown at right or in Appendix A.



Hold this part to insert tip into sleeve assembly and put into the connector.

## ● Control card

Each FM-202 comes with a small card, which inserts into the Card slot on the front of the unit. This card is used when entering data for the process control function (a temperature value is to be changed, or data are to be entered). Any FM-202 card can be used with any FM-202 soldering station.

## ● Changing the temperature setting

**Example:** 700 to 840°F

### 1. Insert the control card into the slot in the front of the unit.

- The *hundreds* digit will begin to flash, indicating that the unit is in the TEMPERATURE SET mode and data may be entered.

### 2. Entering the *hundreds* digit

- Press the ▲ or ▼ button to set the desired value. **Only 4, 5, 6, 7, or 8 can be selected.** (In °C mode, 2, 3, or 4 can be selected.)

When the desired value is displayed, press the \* button to enter. The *tens* digit will begin to flash.

### 3. Entering the *tens* digit

- Press the ▲ or ▼ button to set the desired value. **Any value from 0 to 9 can be selected.** When the desired value is displayed, press the \* button to enter. The *units* digit will begin to flash.

### 4. Entering the *units* digit


- Press the ▲ or ▼ button to set the desired value. When the desired value is displayed, press the \* button to enter. The desired temperature is now entered into the system memory and heater control will begin.

#### NOTE:

If power is switched off or lost during the execution of this procedure, no data will be entered. The entire procedure must be repeated from step 1.


#### ⚠ CAUTION:

The control card must be inserted into the card slot in the correct direction for data to be entered.






**When the station is ON and the control card is in the station, the data entry procedure is:**

- Hold the  button down for at least one second.
- The current temperature setting will be displayed, then the *hundreds* digit will begin to flash. This indicates that the station has entered the temperature setting mode.
- Follow steps 1-4 on the preceding page.

**NOTE:**

When the  button is pressed for less than one second, the current temperature setting is displayed.

## ● Replacing the tip

### Removing and inserting the tip:


Removing the tip: Hold the connector and pull the tip and sleeve assembly out of the connector. (If the tip is hot, hold it with the heat-resistant pad.)

Remove the tip from the sleeve assembly.



Inserting the tip: Hold head part and insert the tip into the sleeve assembly. Push until the sleeve assembly touches the ring round the tip; at this point the tip should not be forced further into the sleeve assembly.

Put the tip into the connector.

Enter Tip ID for new tip (see page 9).

Insert the new tip firmly into the connector. (If the tip is not properly inserted,  will be displayed.)

There are no orientation requirements.




**⚠ CAUTION:**

The tip can be very HOT. Use the heat-resistant pad for handling hot tips, but do not hold the hot portion of the tip, even with the pad, for a long time.

# 7. TIP IDENTIFICATION NUMBER

## ● Entering the Tip ID



**CAUTION:**  
Do not damage or remove the Tip ID bar code sticker.

Soldering tips have different thermal characteristics, depending upon their mass, shape, and surface area. It should be obvious that the tip temperature at idle will not be the same for a fine tip as it will be for a heavy chisel tip, although the set temperature may be the same for each tip. The FM-202 processor incorporates the ability to electronically compensate for tip geometry variations using Tip IDs. Each FM-202 tip style has a specific Tip ID; whenever a tip is changed, the Tip ID should be entered into the FM-202 for most effective process control.

There are two ways to enter Tip ID data into the FM-202:

See below or page 6 of this manual. This procedure is the simplest and most common.

See Appendix A of this manual, when the Tip ID is not readable for some reason.

### Method 1 –

#### How to read out the bar code of the tip into the FM-202:

1. Insert the tip (connector side) into the process gate in the front of the station.
2. Insert the tip until the buzzer sound once. The display shows **5-8**. The LED indicator will stop flashing. Now the tip identification number has been stored.

**NOTE:**  
When the buzzer sounds three times is reading error, insert the tip again.

**CAUTION:**  
Do not insert the tip opposite side or other incompatible tip.

**CAUTION:**  
When tip is inserting the FM-2021, the process gate cannot read the bar code. If a tip insert into the process gate while the tip is already in the FM-2021, buzzer will sound irregularity. Remove the tip from the FM-2021 for reading the Tip ID.


# 8. PARAMETER SETTINGS

## ● Entering the parameters

### (1) °C or °F temperature display

### (2) Auto power shutoff







This is an optional setting. When it is activated and the soldering iron is not used for 30 minutes, the power to the heating element is shutoff automatically and the buzzer will sound three times. When the temperature decreases to 100°C/200°F the display will show ---. To resume soldering, cycle the power switch OFF, then ON. The power will be turned on automatically if you hit any button before the temperature decreases to 100°C/200°F.

To bypass this procedure and continue to resetting the low temperature alarm tolerance setting press the  button once.




The FM-202 has the following four parameters:

- 1) °C or °F temperature display selection
- 2) Auto power shutoff
- 3) Low-temperature alarm tolerance setting
- 4) Supervisor or operator control setting

Once the station enters parameter mode, set the parameters in the order shown below. Once all the parameters have been set, normal operation will be resumed.

1. Turn power OFF.
2. Insert the control card into the card slot in the front of the unit.
3. Press and hold down the  button, and then turn power ON.
4. The display will show the Tip ID for one second. Hold the  or  button down until the display shows 1 C (Celsius) or 1 F (Fahrenheit). When either of these are displayed, the station is in parameter input mode.
  - Pressing either the  or  button will cause the display to alternate between 1 C or 1 F.
  - When the desired scale is displayed, select by pressing the  button. The system will automatically sequence to auto power shutoff mode.

To change the auto power shutoff setting, the procedure is as follows.

- The display will show 2 1 or 2 0 when this mode is entered.
- Using  or  button will change 2 1 and 2 0. The autopower shutoff is operational only when 2 1 is selected.
- Press the  button to enter the parameter. This will store the setting in system memory and the system will automatically sequence to the low temperature alarm tolerance setting mode.

**NOTE:**

Every time the power turn OFF, the Tip ID is not stored to the station. E-E is flashing. read out bar code or entering the Tip ID again.

### (3) Resetting the low temperature alarm tolerance setting

This unique function alerts the operator when the sensed temperature drops below a set limit. Should this occur, an error message **H-E** will be displayed, and the buzzer will sound continuously. When the temperature returns within the allowable range, the buzzer will stop. The value is stored in the FM-202 as described below:

**EXAMPLE:**

If the set temperature is 650°F and the low temperature alarm is 100°F, the alarm will trip when the sensed temperature goes below 550°F.

**NOTE:**

The threshold limits are: 30 – 150°C; 60 – 300°F. If a value outside these limits should be entered, the system will revert to the beginning of the mode, the hundreds digit will flash, and the procedure must be restarted.

To bypass this procedure, press the **✱** button three times.

Range of allowable low-temperature alarm tolerance

For °C: 30 – 150°C

For °F: 60 – 300°F

### (4) Supervisor or operator control setting

This mode allows control over the Tip ID data entry to be assigned to a card-holder.

**NOTE:**

Whether the card is inserted or not, process gate works.

1. When the station enters low-temperature alarm tolerance setting mode, the hundreds digit begun flashing. Enter and store the value in the same manner as described on page 7 “Changing the temperature setting.”
2. If you enter a value exceeding the allowable range shown to the left, you will be brought back to entering a value in the hundreds digit. If this occurs, reenter a correct value.
3. Once the value is stored, the system will automatically sequence to the resetting the supervisor or operator control setting.

To change the control selection, proceed as follows:

1. When the mode is entered, the display will show **4 0** or **4 1**  
**4 0**: Tip ID cannot be entered without inserting the control card.  
**4 1**: Tip ID can be entered without inserting the control card.
2. Pressing either the **▲** or **▼** button will cause the display to alternate between **4 1** and **4 0**.
3. When the desired setting is displayed, select by pressing **✱** button.  
The system will exit the parameter setting mode and begin heater control.  
It is now ready for normal operation.

# 9. MAINTENANCE

---

## ● Tip maintenance

### 1. Tip temperature

High temperatures shorten tip life and may cause thermal shock to components. Always use the lowest possible temperature when soldering. The excellent thermal recovery characteristics of the FM-202 ensure effective soldering at low temperatures.

### 2. Cleaning

Always clean the soldering tip before use, to remove any residual solder or flux adhering to it. Use a *clean and moist* cleaning sponge (provided with the FM-202) or the Hakko 599 tip cleaner. Contaminants on the tip have many deleterious effects, including reduced heat conductivity, which contribute to poor soldering performance.

### 3. After use

Always clean the tip and coat it with fresh solder after use. This guards against oxidation.

### 4. When the unit is not being used and the auto power shutoff is not active.

Never allow the unit to idle at a high temperature for extended periods. This will allow the tip to become oxidized. Turn the power switch OFF. If it is to be out of service for several hours, it is advisable to pull the power plug as well.

### 5. Inspecting and cleaning the tip

This procedure, if followed daily, will materially add to tip life.

- a. Set the temperature to 250°C (482°F).
- b. When the temperature stabilizes, clean the tip (see 2, above) and check the condition of the tip. If the tip is badly worn or deformed, replace it.
- c. If the solder plated part of the tip is covered with black oxide, apply fresh solder, containing flux, and clean the tip again. Repeat until all the oxide is removed, then coat the tip with fresh solder.

**⚠ CAUTION:**  
NEVER file the tip to remove oxides!

- d. Turn the power OFF and remove the tip, using the heat resistant pad. Set the tip aside to cool.
- e. Remaining oxides, such as the yellow discoloration on the tip shaft, can be removed with isopropyl alcohol.

## ● Checking Procedure

**⚠ WARNING:**

Unless otherwise directed, carry out these procedures with the power switch OFF and the power UNPLUGGED.

### ■ Check for a broken heater or sensor

1. Check for a broken heater or sensor


Measure the resistance across this position.



Verify the electrical integrity of the heater and sensor.


Measure the resistance of the heater and sensor while at room temperature (15 to 25°C; 59 to 77°F). It should be  $8\Omega \pm 10\%$ . If the resistance exceeds these limits, replace the tip.

### ■ Check the grounding line



1. Unplug the connection cord from the station.
2. Measure the resistance value between Pin 2 and the tip.
3. If the value exceeds  $2\Omega$  (at room temperature), perform the tip maintenance described on p.12. If the value still does not decrease, check the connection cord for breakage.

### ■ Checking the connection cord for breakage




1. Remove the soldering tip and the sleeve assembly.
2. Turn the front piece of the FM-2021 clockwise and remove the cover.
3. Measure the resistance values between the connector and the lead wires at the socket as follows:

Pin 1 – Red    Pin 2 – Green  
Pin 3 – Black    Pin 5 – White

If any value exceeds  $0\Omega$  or is  $\infty$ , replace the FM-2021.


### ■ Replacing the fuse



1. Unplug the power cord from the power receptacle.
2. Remove the fuse holder.
3. Replace the fuse.
4. Put the fuse holder back in place.

# 10. ERROR MESSAGES

## ● Sensor Error




When there is the possibility that a failure has occurred in the sensor or heater (including the sensor circuit), **S-E** is displayed and the power is shut down.

**NOTE:**


The sensor error also occurs if the tip is not inserted properly.

## ● Low-temperature alarm tolerance error



If the sensor temperature falls below the difference between the current temperature setting and the low-temperature alarm tolerance, **H-E** is displayed and the warning buzzer sounds. When the tip temperature rises to a value within the set tolerance, the buzzer will stop sounding.

**EXAMPLE:**



**EXAMPLE:**


Assume that the temperature setting is 400°C/750°F and the tolerance 50°C/100°F. If the temperature continues to decrease and finally falls below the value indicated below while the heating element is on, the displayed value starts blinking to indicate that the tip temperature has dropped.

## ● Heater terminal short circuit error



**HSE** will flash, and the buzzer will sound continuously, when the tip is inserted wrong way round, an incompatible tip is inserted, or a foreign object has found its way into the connector.


## ● Tip ID error



**T-E** will flash, and the buzzer will sound three times, if the process gate cannot read the Tip ID.

**T-E** will be displayed if Tip ID has not been entered.

## ● Soldering iron error



**I-E** will be displayed, and the buzzer will sound continuously, if the connector cord is not attached to the station OR the wrong soldering iron is connected.

# 11. TROUBLE SHOOTING GUIDE

## **WARNING:**

- Before checking the inside of the FM-202 or replacing parts, be sure to disconnect the power plug. Failure to do so may result in electric shock.

### ● The unit does not operate when the power switch is turned on.


**CHECK** : Is the power cord and/or the connection plug disconnected?

**ACTION** : Connect it.

**CHECK** : Is the fuse blown?

**ACTION** : Investigate why the fuse blew and then replace the fuse. If the cause can not be determined, replace the fuse. If the fuse blows again, send the unit in for repair.

### ● The tip does not heat up.

- The sensor error  is displayed.

**CHECK** : Is the power cord disconnected?

**ACTION** : Connect it.

**CHECK** : Is the tip inserted properly?

**ACTION** : Insert the tip completely.

**CHECK** : Is the connection cord and/or the heater/sensor broken?

**ACTION** : See the appropriate section of this manual regarding how to check the connection cord and/or the heater/sensor for breakage.

### ● Solder does not wet the tip.

**CHECK** : Is the tip temperature too high?

**ACTION** : Set the appropriate temperature.

**CHECK** : Is the tip contaminated with oxide?

**ACTION** : Remove the oxide (see "Tip maintenance" on P. 12).

### ● The tip temperature is too high.

**CHECK** : Is the connection cord broken?

**ACTION** : See "Checking the connection cord for breakage" on P. 13.

**CHECK** : Is the entered tip identification number correct?

**ACTION** : Enter the correct value.

### ● The tip temperature is too low.

**CHECK** : Is the tip contaminated with oxide?

**ACTION** : Remove the oxide (see "Tip maintenance" on P. 12).

**CHECK** : Is the entered tip identification number correct?

**ACTION** : Enter the correct value.

### ● The soldering iron error is displayed.

**CHECK** : Is the other soldering iron connected? Or the FM-2021 plug disconnected?

**ACTION** : Turn the power switch OFF and connect the FM-2021 or Hakk 912 soldering iron. Turn the power switch ON.



---

● The low-temperature alarm tolerance error **H-E** occurs frequently.

● Tip ID error **L-E** is displayed

● Heater terminal short circuit error **HSE** is displayed

**CHECK** : Is the tip too small for the items to be soldered?

**ACTION** : Use a tip with a larger thermal capacity.

**CHECK** : Is the setting value for the low-temperature alarm tolerance too low?

**ACTION** : Increase the setting value.

**CHECK** : Is the procedure of the entering tip identification number correct?

**ACTION** : Entering correctly.

**NOTE:**

If reinsert the tip into the process gate and buzzer sounding three times. Try to insert again or entering the Tip ID by hand operation.

**CHECK** : Is the tip for FM-2021?

**ACTION** : Turn the power switch OFF and insert the genuine FM-2021 tip. Turn the power switch ON.

**NOTE:**

This error does not display when not entering the Tip ID.


# 12. PARTS LIST


**NOTE:**

Spare or repair parts do not include mounting screws, if they are not listed on the description. Screws must be ordered separately.



● **FM-202 Station**

Item No.	Part No.	Part Name	Description
1	B2749	Control card	
2	B2741	Front panel	with control panel, display window and slit
3	B2742	Button set for control panel	4 each
4	B2745	P.W.B. (temperature setting, display and process gate)	Set of 4
5	B2747	Process gate switch	
6	B2746	Process gate support	
7	B2744	P.W.B. (temperature control and connector)	Set of 2
8	B2748	Rubber foot	4 each
9	B2740	Chassis	with rubber foot
10	B2757	Locking spacer	5 each
11	B2743	Transformer	120V
12	B2384	Power receptacle	
13	B2761	Fuse, 250V-3A	
14	B1084	Power switch	
15	B2739	Cover	
16	B2419	Power cord, 3 core & American plug	





Item No.	Part No.	Part Name	Description
1	FM2021-01	Connector assembly	
2	B2750	Sleeve	
3	B2751	Sleeve stopper	With O-rings
4		Tip	
5	B2300	Heat resistant pad	




### ● Iron Holder


Item No.	Part No.	Part Name	Description
1~5	C1459	Iron holder	

### ● Iron Holder Parts

Item No.	Part No.	Part Name	Description
1	B2753	Iron receptacle	With two screws
2	B2754	Iron holder base	(With bottom plate, rubber foot)
3	A1490	Cleaning sponge	
4	B2405	Rubber foot	4 ea.
5	B2755	Retaining clip	
6	B2756	Tip tray	




# 13. TIP STYLES




Unit: mm (in.)


T7-D08 SHAPE-0.8D Chisel




T7-D12 SHAPE-1.2D Chisel




T7-D16 SHAPE-1.6D Chisel




T7-D24 SHAPE-2.4D Chisel




T7-D32 SHAPE-3.2D Chisel




T7-D4 SHAPE-4D Chisel




T7-D52 SHAPE-5.2D Chisel




T7-B SHAPE-B Conical




T7-B2 SHAPE-2B Conical




T7-I SHAPE-I Sharp Conical




T7-LI SHAPE-LI Long Sharp Conical




T7-J02 SHAPE-0.2RSB Bent




T7-JL02 SHAPE-0.2RLB Bent




T7-JS02 SHAPE-0.2RSSB Bent




T7-C1 SHAPE-1C Bevel




T7-BC1 SHAPE-1BC Bevel




T7-BCF1 SHAPE-1BC Bevel  
(Tinned on the soldering surface only)




T7-BC12 SHAPE-1.2BC Bevel  
(Tinned on the soldering surface only)




T7-BC15 SHAPE-1.5BC Bevel  
(Tinned on the soldering surface only)




T7-BC2 SHAPE-2BC Bevel




T7-BCF2 SHAPE-2BC Bevel  
(Tinned on the soldering surface only)




T7-BC28 SHAPE-2.8BC Bevel  
(Tinned on the soldering surface only)




T7-BC3 SHAPE-3BC Bevel




T7-BCF3 SHAPE-3BC Bevel  
(Tinned on the soldering surface only)




T7-C4 SHAPE-4C Bevel




T7-CF4 SHAPE-4C Bevel  
(Tinned on the soldering surface only)




T7-KF SHAPE-KF Knife




T7-KL SHAPE-KL Knife




T7-KU SHAPE-KU Knife




T7-R20 SHAPE-2.0R Slot




T7-R23 SHAPE-2.3R Slot




T7-R27 SHAPE-2.7R Slot




T7-R34 SHAPE-3.4R Slot




T7-R48 SHAPE-4.8R Slot




T7-1001 SOP5.1 x 4.6




T7-1002 SOP5.1 x 10.4




T7-1003 SOP9.5 x 18.3




T7-1004 SOP9.5 x 15.8




T7-1005 SOP9.5 x 13.2




T7-1006 SOP6.9 x 11.4




T7-1007 SOP7.9 x 18.8




T7-1008 SOP19.5 x 10.2




T7-1009 SOP13.4 x 20.5




T7-1201 PLCC13.6 x 8.5




T7-1202 PLCC10.3 x 10.3




T7-1203 PLCC12.8 x 12.8




T7-1204 PLCC17.9 x 17.9




T7-1205 PLCC23.4 x 17.3




T7-1206 PLCC22.5 x 16.5




T7-1207 PLCC15.5 x 15.5




T7-1208 PLCC15.8 x 15.8



T7-1209 PLCC8.4 x 8.4



T7-1401 Spatula 15.7



# 14. APPENDIX A


## How to enter the tip identification number into the FM-202:

1. Insert the card to unlock the system.
2. Press the **#** button and hold for more than one second.
  - The station will go into Tip ID input mode. The *tens* place digit begins to flash. Refer to the tip identification number marked on the bar code sticker.

**NOTE:**  
When the **#** button is pressed for less than one second, the stored Tip ID settings are displayed.


3. Entering a value in the *tens* place digit
  - Using the **▲** or **▼** button, enter a value in the *tens* place digit. When the entered value is displayed, press the **\*** button. The *units* digit begins to flash.
4. Entering a number in the *units* digit
  - Perform the same steps used to enter the value in the *tens* place digit. After entering a number in the *units* digit, press the **\*** button. The display shows **S-E** will be flashing. Now the tip identification number has been stored. The temperature will be controlled using this tip identification number.

**Example:**  
When the tip identification number is 07.



**NOTE:**  
When tip is inserting the FM-2021 and changing the Tip ID, no display **S-E** but display the setting temperature.

# 15. WIRING DIAGRAM



**HAKKO CORPORATION**

**HEAD OFFICE**

4-5, SHIOKUSA 2-CHOME, NANIWA-KU, OSAKA, 556-0024 JAPAN

TEL: +81-6-6561-3225 FAX: +81-6-6561-8466

<http://www.hakko.com>

**AMERICAN HAKKO PRODUCTS, INC.**

28920 N. AVENUE WILLIAMS VALENCIA CA 91355, U.S.A.

TEL: (661) 294-0090 FAX: (661) 294-0096

Toll Free (800)88-HAKKO [www.hakkousa.com](http://www.hakkousa.com)

4 2 5 5 6