HAKKO 631
IRON HOLDER


Instruction Manual

Sep., 1997


⚠ CAUTION

Spring iron holder will become extremely hot. Make sure these areas do not come directly into contact with your bare skin.


■Single holder




■Double holders




■For HAKKO 802·809



■For HAKKO 373



■For HAKKO 903·904



■Outer Dimensions

- ●Iron holder base 80mm×137mm(3.1in.×5.4in.)
- ●Inside diameter of iron receptacle
  M/L.....30mm(1.2in.) S.....28mm(1.1in.) 802·809.....31mm(1.2in.)
  903·904.....26.5mm(1.0in.)

■Set Contents


No.	Name	Contents
631-01	HAKKO 631 M/L Single holder	●Spring iron holder M/L (1) ●Iron holder base (1)●Cleaning sponge (1)
631-02	HAKKO 631 S Single holder	●Spring iron holder S (1) ●Iron holder base (1)●Cleaning sponge (1)
631-03	HAKKO 631 M/L+M/L Double holders	●Spring iron holder M/L (2) ●Iron holder base (1)●Cleaning sponge (1)
631-04	HAKKO 631 M/L+S Double holders	●Spring iron holder M/L (1),S (1) ●Iron holder base (1)●Cleaning sponge (1)
631-05	HAKKO 631 S+S Double holders	●Spring iron holder S (2) ●Iron holder base (1)●Cleaning sponge (1)
631-06	HAKKO 631 for 802·809	●Spring iron holder/for HAKKO 802•809 (1) ●Iron holder base (1)●Cleaning sponge (1) ●Cleaning pin holder (1)
631-07	HAKKO 631 for 373	●Spring iron holder B /for HAKKO 373 (1) ●Iron holder base (1)●Cleaning sponge (1)
631-09	HAKKO 631 for 903·904	●Spring iron holder/for HAKKO 903•904 (1) ●Iron holder base (1)●Cleaning sponge (1)


Note


When using the 373,

Please place the iron so that guide pipe of the 373 is to the right or left of the tip.
Placing the guide pipe above the tip will melt the solder inside of the guide pipe.


HAKKO








■ハッコー 373・374用



■ハッコー 904用



■ハッコー373・374ご使用時には

こてを差し込む場合、373・374の送りパイプがこて先の右側あるいは左側にくるようにしてください。送りパイプがこて先の上側にくると送りパイプ内のはんだが溶ける恐れがあります。

■寸　法

●ベース寸法　80mm×137mm

●こてホルダー差込口内径

M/L用……30mm　S用……28mm　802・809用……31mm

904用……26.5mm

■セット明細

品番	品名	セット明細
631-01	ハッコー631M/L用 (こて1本用)	●スプリング式こてホルダー/M,L用　1ヶ ●こて台ベース　1ヶ●クリーニングスポンジ　1ヶ
631-02	ハッコー631S用 (こて1本用)	●スプリング式こてホルダー/S用　1ヶ ●こて台ベース　1ヶ●クリーニングスポンジ　1ヶ
631-03	ハッコー631M/L+M/L用 (こて2本用)	●スプリング式こてホルダー/M,L用　2ヶ ●こて台ベース　1ヶ●クリーニングスポンジ　1ヶ
631-04	ハッコー631M/L+S用 (こて2本用)	●スプリング式こてホルダー/M,L用　1ヶ, S用　1ヶ ●こて台ベース　1ヶ●クリーニングスポンジ　1ヶ
631-05	ハッコー631S+S用 (こて2本用)	●スプリング式こてホルダー/S用　2ヶ ●こて台ベース　1ヶ●クリーニングスポンジ　1ヶ
631-06	ハッコー631 (802・809用)	●スプリング式こてホルダー/802・809用　1ヶ ●こて台ベース　1ヶ●クリーニングスポンジ　1ヶ ●クリーニングピン差し　1ヶ
631-07	ハッコー631 (373・374用)	●スプリング式こてホルダーB/373・374用　1ヶ ●こて台ベース　1ヶ●クリーニングスポンジ　1ヶ
631-09	ハッコー631 (904用)	●スプリング式こてホルダー/904用　1ヶ ●こて台ベース　1ヶ●クリーニングスポンジ　1ヶ

■交換部品

品番	品名/仕様
A1042	クリーニングスポンジ
B1468	スプリング式こてホルダー/M,L用 (900M,900L,ダッシュ,マッハI用) 黒色のチューブ付
B1469	スプリング式こてホルダー/S用(900S用) 黄色のチューブ付
B1094	スプリング式こてホルダー/802・809用 赤色のチューブ付
B1648	スプリング式こてホルダーB/373・374用
B1857	スプリング式こてホルダー/904用 青色のチューブ付
B1470	こて台ベース
B1095	クリーニングピン差し

※スプリング式こてホルダーは、チューブの色により使いわけてください。

HAKKO
白光株式会社
大　阪／〒556 大阪市浪速区塩草2丁目4番5号
TEL:大阪営業(06)561-1574(代) FAX:(06)568-0821
海外営業(06)561-3225(代) FAX:(06)561-8466
東　京／〒101 東京都千代田区神田佐久間河岸85号地
TEL:(03)3866-1161(代) FAX:(03)3866-1164
仙　台／〒983 宮城県仙台市宮城野区榴岡4丁目13番1号
(サンアドバンスビル3F)
TEL:(022)296-5481 FAX:(022)296-5480
工　場／堺・上月