白光株式会社
http://www.hakko.com/
〒556-0024 大阪市浪速区塩草2丁目4番5号
TEL:(06)6561-1574(代)FAX:(06)6568-0821

HAKKO CORPORATION
HEAD OFFICE
4-5, Shiokusa 2-chome, Naniwa-ku, Osaka 556-0024 JAPAN
TEL:+81-6-6561-3225 FAX:+81-6-6561-8466
http://www.hakko.com E-mail:sales@hakko.com
OVERSEAS AFFILIATES
U.S.A.: AMERICAN HAKKO PRODUCTS, INC.
TEL: (661) 294-0090 FAX: (661) 294-0096
Toll Free (800)88-HAKKO
http://www.hakkousa.com
HONG KONG: HAKKO DEVELOPMENT CO., LTD.
TEL: 2811-5588 FAX: 2590-0217
http://www.hakko.com.hk
E-mail:info@hakko.com.hk
SINGAPORE: HAKKO PRODUCTS PTE., LTD.
TEL: 6748-2277 FAX: 6744-0033
http://www.hakko.com.sg
E-mail:sales@hakko.com.sg
Please access to the following address for the other Sales affiliates.
http://www.hakko.com

Copyright © 2012 HAKKO Corporation. All Rights Reserved.

2012.9
MA02534XZ120913

HAKKO FH-800
IRON HOLDER

FH800-03/04

取扱説明書

●

お買い上げいただきありがとうございます。
この説明書をお読みになり、正しくお使いください。
お読みになった後も大切に保管してください。

●

⚠ 注意　こてホルダーは高温となりますのでやけどにご注意ください。



使用上のご注意：

＊ クリーニングスポンジは必ず水を含ませてご使用ください。

■FH800-04

ハッコーFX-888Dの付属のこて台FH-800を使用されている場合は下図のように口金を引き抜き、FH800-04用の口金を差し込んでください。



● こて台パーツ

品番	部品名	仕様
A1559	クリーニングスポンジ	
B3472	こて台本体/ブルー・イエロー	Pキャップ、ゴム足付
B3473	こて台本体/シルバー	Pキャップ、ゴム足付
B3751	屑受け	ゴム足付
A1561	クリーニングワイヤー	
B3666	口金	FH800-04用

● オプション

品番	部品名	仕様
B3474	マウスキャップ	

HAKKO

English | 中文 | 日本文

HAKKO FH-800 IRON HOLDER

FH800-03/04

使用説明書

日本白光牌

●

感謝您購置焊鐵座。
使用焊鐵座之前,請詳閱本説明書。
閱後請妥為收存,以備日後查閱。

●

⚠ **注意:** 當使用時焊鐵座溫度會昇高,請勿接觸其部分可能導致燙傷。



使用上的注意:

＊ 海綿是擠壓物體,水濕則漲大。使用海綿時,先濕水再擠乾。否則會損壞焊鐵頭。

■FH800-04

使用HAKKO FX-888D附屬的焊鐵座FH-800時，請如右圖所示，拔出蓋帽，插入鑷子插架。



●焊鐵座用部件

部件編號	部件名稱	規格
A1559	清潔海綿	
B3472	焊鐵架底座/藍色-黃色	附橡膠腳
B3473	焊鐵架底座/銀色	附橡膠腳
B3751	焊鐵臺底座	附橡膠腳
A1561	清潔金屬絲	
B3666	鑷子插座	FH800-04用

●另購配件

部件編號	部件名稱	規格
B3474	橡膠清潔口	

HAKKO

English | 中文 | 日本文

HAKKO FH-800 IRON HOLDER

FH800-03/04

INSTRUCTION MANUAL

●

Thank you for purchasing the iron holder.
Please read this manual before using the iron holder.

●

⚠ **CAUTION:** The iron holder will become extremely hot. Do not touch them.



NOTE:

The sponge is compressed. It will swell when moistened with water. Before using the unit, dampen the sponge with water and squeeze it dry. Using a dry sponge will damage the soldering tip.

■ FH800-04

If you use the iron holder for FH-800 included with HAKKO FX-888D, remove the iron receptacle and insert the holder clip as the figure below indicates.



● Iron Holder Parts

Part No.	Part Name	Specifications
A1559	Cleaning sponge	
B3472	Iron holder base/Blue-yellow	BY with rubber foot
B3473	Iron holder base/Silver	SV with rubber foot
B3751	Bottom plate	with rubber foot
A1561	Cleaning wire	
B3666	Holder clip	For FH800-04

● Optional Parts

Part No.	Part Name	Specifications
B3474	Rubber cleaner	